



K9 HEATER

FITTING INSTRUCTIONS

Read all instructions before installing or using this heater

Tools Required:- You will need a drill, tape measure, 50mm holesaw, screwdriver and 4 wood screws (not supplied).



Step 1. Place the mounting template in desired position of the K9 Heater to mark screw and plug holes.

The K9 heater must be fixed as follows:-

Ceiling to top of heater - Min 100mm

Each side of heater to side of kennel - Min 100mm

Bottom of heater to floor / bedding - Min 500mm

It is important to make sure that there is sufficient minimum distance from the bottom of the heater to the top of the dog when lying / standing. There needs to be a gap of at least 200mm clear air space if the dog is able to be directly under the heater output at the bottom. This is to allow the warm air to circulate freely and avoid overheating of the K9 Heater (using our wire guard can overcome this issue).



Step 2. Screw the top 2 wood fixing screws in place, leaving the screw head proud to allow the heater to be hooked over and fit flush and securely to the side wall of the kennel. Drill a hole through the sidewall of the kennel with the 50mm holesaw.

Step 3. Feed the plug and cable all the way through the hole making sure the cable is not pinched or kinked.



Step 4. Hook the heater over the top screws, making sure the heater fits securely. Gently pull any slack in the cable through the hole from the outside of the kennel.



Step 5. Fix the bottom of the heater with the 2 remaining wood screws through the eyelets on the bottom of the heater.

Step 6. All done! Plug in and set to the desired temperature.



These instructions are for guidance when fitting the K9 Heater to a wooden kennel. If fitting to other materials please make sure that correct suitable fixings are used.