



K9 HEATER

IMPORTANT SAFETY INSTRUCTIONS

READ THE INSTRUCTIONS BEFORE USING THE APPLIANCE

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Warning - In order to avoid overheating do not cover the heater or obstruct air outlets.
- This heater has been fitted with a non resetting thermal cut out safety device to prevent overheating and to ensure the safety of your pet. If your heater cuts out, unplug it from the mains supply socket.
- Do not use this heater with a programmer, timer, separate remote control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- If the supply cord becomes damaged, it must be replaced by the manufacturer, its service agents or similarly qualified personal
- Prevent water from getting into the unit including when it is in storage
- Do not insert objects into any of the openings on the heater as this may cause electrical shock or overheating
- This product is a wall mounted appliance
- This product is suitable for installation on surfaces with normal flammability e.g. wood, plasterboard, masonry.
- Do not use the heater if the power cord is damaged.
- The heater should not be mounted above or below any socket outlets.

To prevent excessive dust building up and entering your K9 Heater we recommend that you regularly clean it.

- Always disconnect the heater from the mains supply and allow it to cool down before cleaning.
- Clean the outside of the heater by wiping with a damp cloth and buff with a dry cloth. Do not use any detergents or abrasives and do not allow any water to enter the heater.